

AN496/D

Using MC683xx M-bus software to communicate between processor systems

James Gilbert,
Applications Group, High-Performance Products,
Motorola Ltd., East Kilbride, Scotland.

Introduction

M-bus is an I2C-compatible bus interface used in the 683xx family. It is a serial interface comprising two open-drain, bidirectional signals, namely serial clock (SCL) and serial data (SDA). Multiple devices can be connected directly to these open-drain lines, and indeed this is good reason for the widespread adoption of the bus as an efficient IC communication method in end-systems.

A typical scenario would consist of a processor with an M-bus master controlling the data flow between several slaves, such as LCDs, real-time clocks, keypads, A/D converters and memories. Moreover, a built-in bus collision mechanism supports multiple M-bus masters as well as multiple slaves. The M-bus module of the 683xx is flexible enough to operate as either an M-bus master or a slave.

This application note demonstrates control software for M-bus communication between two identical MC68307 systems, one configured with an M-bus master and the other an M-bus slave. Only a short piece of initialisation code needs to be changed to make the MC68307 code applicable to other 683xx devices with M-bus.

Overview of M-bus Software Transfer Mechanism

For full details of M-bus features, and a complete specification of the M-bus module, refer to the MC68307 User Manual. For the sake of clarity, a brief overview of the software control mechanism is provided here.

The M-bus communication is on a byte-wide basis. The components of the hardware transfer protocol are a START condition, 8 data bits, an acknowledge bit and a STOP condition. Before starting a communication, an M-bus master should carry out a software check to ensure the bus is free, and therefore all other M-bus transfers are complete. Thereafter, the bus master initiates a transfer by software writing a START condition onto the bus. This is an indicator to all connected M-bus devices that this master is taking charge of the bus, and that the address of the targeted slave is to follow. For the 683xx M-bus master, writing the targeted slave address to the data register initiates the 8-bit transfer (MSB first).

If a system has two or more M-bus masters which poll the bus free and start a transfer at the same time, then the collision detection arbitration, throughout the transfer of the slave address transfer and subsequent data bytes, decides which device gets charge of the bus. If the 683xx M-bus loses arbitration in this way, it stops driving data onto the bus, to prevent data corruption. Furthermore, it switches automatically into slave mode pre-empting the alternate master addressing it as a slave. If interrupts are enabled, an interrupt is generated on the completion of that byte, and a status bit indicates arbitration lost as the interrupt source.

The first data byte transmitted by the M-bus master is always the targeted slave address, with the least significant bit determining whether the slave remains ready to receive or transmit subsequent bytes. The addressed slave can then acknowledge the received byte, or not, depending upon the software protocol and acknowledge capability of the slave devices used. Each acknowledge is like a 9th data bit, asserted by the receiver as a handshake to successfully transmitted data.

A block transfer comprising a series of data bytes (and acknowledges, if used) follows as commanded by the software protocol. The bus remains busy throughout the block, precluding all other masters from starting transfers. At the end of the block, the bus master relinquishes the bus by software placing a STOP condition onto the bus.

Ultimately, the M-bus master is responsible for starting and stopping transfers, but the number of bytes transferred can be dictated by either the master or slave depending upon the desired software protocol. For example, a slave may acknowledge all bytes received until it saturates, at which point the master STOPS the block transfer. Alternatively, the slave receiver may acknowledge received bytes until the master transmitter dictates there are no more bytes to send. Indeed, both master and slave can be charged with controlling the transfer block. For instance, the software protocol may transfer a byte count as part of the communication, or use a fixed number of transfer bytes every time.

For the best choice in software control, transfers can adopt either a status polling method, or interrupts at the end of each byte. The interrupt option is most commonly used to minimise the time the processor is tied up with the transfers (overhead). If enabled, the interrupts are generated on the completion of each 9 bits (8 data bits plus an acknowledge).

M-bus Master Mode Operation

Using interrupts to transmit data to the addressed slave is straightforward. During the M-bus initialisation, the 683xx M-bus sets up master transmitter mode, sets the M-bus frequency, enables interrupts, provides an interrupt handler and STARTs the block transfer. The targeted slave address (with lsb = 1 for slave receiver mode) is transmitted by writing to the M-bus data register. On each subsequent end-of-byte interrupt, further data bytes are transmitted by writing data to the M-bus data register until the block is complete. On the interrupt at the end of the last byte the software STOPS the transfer.

For receiving from the addressed slave, the initialisation is exactly the same. Remember that even if receiving, the first operation is to transmit the targeted slave address (except this time lsb = '0'). In the interrupt handler at the end of the slave address transmit byte, the transmit mode is changed to receive. Then, to initiate the first byte receive operation, the 683xx M-bus master software carries out a dummy read of the data register. No sensible data is read at this point, but it is the action of this read which starts the data receive. At the end of each received byte, the interrupt generated is used to read the data register again for valid data, and to start the next byte receive. This continues until the master receiver STOPS the block transfer.

The receiver is always responsible for the generation of acknowledges. The 683xx M-bus receiver can be programmed to generate acknowledges automatically for each byte received if desired. Most slave transmitters take an acknowledge from the master receiver to mean that further bytes are desired. In fact, for some slave transmitters, it is necessary for the master receiver to acknowledge all received bytes (except the last one), to indicate that more data byte transmits are required. This is not a requirement of the 683xx M-bus slave.

M-bus Slave Mode Operation

Many of the principles discussed for the master operation also hold true for the slave 683xx M-bus. The main differences are that the M-bus is no longer controlling the transfer (STARTing and STOPping) or the provider of the M-bus clock, but is instead following what the master dictates.

For slave operation, again initialise the M-bus frequency, M-bus slave address, interrupt handler and interrupt enable. As the first transfer is always the receipt of the slave address, slave receive mode should always be programmed initially. All target slave addresses which are transmitted by the master (first byte after START) are then checked against the programmed 683xx M-bus slave address for a match. When they match, an interrupt is generated (if enabled), and a status bit indicates the cause as M-bus addressed-as-slave (MAAS).

On entering the corresponding interrupt handler, the software read/write status indicator is read to determine whether the slave is to receive or transmit subsequent bytes, and the transmit/receive mode set accordingly. If in transmit mode, the first data byte transmit is initiated by writing to the data register. If in receive mode, the first receive byte is

initiated by a dummy read of the data register. There is no sensible data read at this point, but having started the receive process, data register reads in subsequent end-of-byte interrupts read valid data and initiate the next byte receive. Again, the software protocol determines the use of acknowledges.

For a fuller description of the M-bus software and hardware features, see the MC68307 users' manual.

Description of Set-up

The hardware consists of two identical MC68307 systems connected together via the M-bus as shown in Figure 1. Both are master-mode processor systems, each with the MC68307 processor core executing instructions prefetched from ROM. This is not to be confused with the master and slave operation of the M-bus modules within each processor.




Figure 1 Hardware Setup

Each MC68307 system has 128kB EPROM and 128kB SRAM and runs a debug monitor. A complete description of the system hardware is provided in AN490/D, "Multiple Bus Interfaces using the MC68307".

Using the monitor's download facility, an M-bus control program is downloaded into the SRAM of each board. The code allows one system to control its M-bus module as a master, while the other implements an M-bus slave. Together, the two software programs allow the MC68307 M-bus master to write data to the M-bus slave and later read it back for verification.

Software Flow

The MC68307 master M-bus controls the number of blocks transferred via START and STOP conditions. In this example, there are only two communication blocks, one transmitting data to the slave (master transmit block), and one receiving data back from the slave for verification (master receive block). The master/slave responsibilities during the master transmit block are outlined in Figure 2a and for the master receive block in Figure 3a.

On these diagrams, note that for a given transfer byte, the end-of-byte interrupts on the master and slave occur at around the same time. The built-in M-bus transfer mechanism means it does not matter in which order they are serviced. The master and slave interrupt service order used in the flowcharts of Figures 2a and 3a is purely for demonstration purposes. The interrupt handlers are shown such that the data flow is always from transmitter to receiver. It should be understood that the master and slave interrupt handlers are happening at the same time, as are the transmit and receive of a particular byte.

Transfer Blocks

The master M-bus controls the number of data bytes within each transmit/receive block. Observe Figures 2b and 3b, which give a summary of the activity on the M-bus during the master transmit and master receive blocks respectively.

When the master is transmitting data (master transmit block), the slave acknowledges all bytes received, and the master decides when the transfer is completed by setting a STOP condition; see Figure 2b. When the master is

receiving data (master receive block), it decides when the transfer is complete by stopping acknowledges on the last received byte, (thereby stopping the slave transmitting) and setting a STOP condition; see Figure 3b.

Software Implementation

The software used is shown in Software listing 1 and 2. Only the method of enabling the M-bus and interrupts at the start of the software listings is specific to the MC68307. Thereafter, the code is generic for any 683xx device with an M-bus module.

The 683xx M-bus slave software should always be set running before the master software, such that the prospective slave is initialised as a receiver before the master transmits the slave address.

The software uses interrupts to control the byte transfers within each block. The M-bus master starts the transfer by transmitting the slave address. Thereafter interrupts are generated on both the master and slave M-bus to control the test. The M-bus hardware protocol does not care which order the interrupts are serviced by the master (transmitter or receiver) or slave (transmitter or receiver) at the end of each byte. Consider that the master is in charge of generating the SCL clocks to shift data out the transmitter and into the receiver, when a transmit/receive is initiated by writing/reading the M-bus data register respectively. However, the clocks do not start until the slave has released the clock line on the bus by making its corresponding read/write of its M-bus data register. Therefore, both 683xx M-bus master and slave interrupts have to initiate the next data transfer.

The slave frequency can be programmed as greater or less than that of the master. M-bus implements a clock synchronisation mechanism such that the clock with the shortest high time and longest low time dictates the open-drain clock. For example, if the programmed slave M-bus clock frequency is less than the master, the slave can stretch the clock as necessary.

The number of transfer and receive blocks, and the number of data bytes within each block can be altered in the master software. The slave software remains the same throughout. If the user desires detailed crosschecks on the software flow, interrupt counts (for number of bytes transferred) or a flag passing mechanisms could be implemented. For simplicity this is not used in the example software.




Figure 2a Master/Slave Responsibilities for the Master Transmit Block

Master Activity	Start Block	Tx Slave Address (Slave to Rx)		Tx 1st data byte		Tx 2nd data byte		Stop Block
M-bus	Start	66	Ack	AA	Ack	55	Ack	Stop
Slave Activity		Rx Slave Address	Ack	Rx 1st data byte	Ack	Rx 2nd data byte	Ack	

Figure 2b Summary of M-bus Activity for the Master Transmit Block




Figure 3a Master/Slave Responsibilities for the Master Receive Block

Master Activity	Start Block	Tx Slave Address (Slave to Tx)		Rx 1st data byte	Ack	Rx 2nd data byte	No Ack	Stop Block
M-bus	Start	67	Ack	AA	Ack	55	No Ack	Stop
Slave Activity		Rx Slave Address	Ack	Tx 1st data byte		Tx 2nd data byte		

Figure 3b Summary of M-bus Activity for the Master Receive Block

Software Listing 1 - M-bus Master Software

```

*****
*          MOTOROLA 68307 IMBP TEST BOARD - MBUS          *
*-----*
*          MODULE:  MBM_INT.SRC          DATE:    8/4/94    *
*          *
*          Developed by : Motorola          *
*          HI-END Applications          *
*          East Kilbride.          *
*          *
*          NOTES:          *
*          Master MBUS Routine using interrupts for a Master/Slave Test          *
*          *
*          The number of bytes transmitted and received is completely          *
*          controlled by the master. (i.e. When the slave is receiving data,          *
*          it acknowledges all the time, and the master dictates the number of          *
*          bytes to transfer. When the slave is transmitting, the master          *
*          receiver acknowledges dictate whether the slave is to send further          *
*          bytes or not.)          *
*          *
*          The Master:          *
*          1) Writes out the slave chip address, and 2 slave data bytes.          *
*          2) Writes out the slave chip address, and reads 2 slave data bytes.          *
*          3) Verifies the data read back against that originally sent.          *
*          *
*-----*
*          EXTERNAL REFERENCE DECLARATIONS          *
*-----*
*          XREF          SCR          System Control Reg          *
*          XREF          PBCNT          Port B Control Reg          *
*          XREF          PIVR          Peripheral Interrupt Vector Reg          *
*          XREF          PICR          Peripheral Interrupt Control Reg          *
*          XREF          MADR          MBUS Address Reg          *
*          XREF          MFDR          MBUS Freq Divider Reg          *
*          XREF          MBCR          MBUS Control Reg          *
*          XREF          MBSR          MBUS Status Reg          *
*          XREF          MBDR          MBUS Data Reg          *
*          *
*-----*
*          Constants          *
*-----*
*          UVECBASE          EQU          $100          User Vector Base          *
*          MBUSVEC          EQU          UVECBASE+($D*4)          MBUS vector location          *
*          MBUSHAN          EQU          $15000          MBUS Interrupt Handler location          *
*          *
*          S307_AD          EQU          $66          Slave 68307 Mbus Address          *
*          DRXCNT          EQU          $3          Data RECEIVE COUNT (2 + 1 Dummy)          *
*          ATXCNT          EQU          $1          Address TRANSMIT COUNT          *
*          DTXCNT          EQU          $2          Data TRANSMIT COUNT          *
*          *
*-----*
*          Main Program          *
*-----*
*          ORG          $10000          RANDOM LOCATION FOR ASSEMBLY          *
*          AND.L          #$FFFFFFF,SCR          Clear SCR bit 8, MBUS CLock Active          *
*          MOVE.B          #$40,PIVR          Vector = #$40, Vector @ address $100          *
*          OR.W          #$000D,PICR          MBUS Interrupt level = 5          *
*          MOVE.L          #MBUSHAN,MBUSVEC          Set up MBUS Interrupt Handler          *
*          OR.W          #$0003,PBCNT          Enable MBUS Lines          *
*          BSR          INIT_MBM          Initialise Mbus as master          *
*          *
*          * WRITE TO SLAVE 68307 Mbus          *
*          * Write Chip Address, and Two bytes of data          *
*          START          BSR          MBBUSY          Poll the MBUS, wait till bus free          *
*          *
*          MOVE.B          #0,V_DRXCNT          Data RECEIVE COUNT          *
*          MOVE.B          #ATXCNT,V_ATXCNT          Address TRANSMIT COUNT          *
*          MOVE.B          #DTXCNT,V_DTXCNT          Data TRANSMIT COUNT          *
*          MOVE.B          #1,V_WRITE          Set Write to slave var = TRUE          *
*          MOVE.B          #S307_AD,V_CHIPAD          Slave 68307 Mbus receiver Address          *
*          MOVE.L          #S307_DATA,A0          Pointer to stored data for transfer          *
*          *
*          BSR          WRITE1          Send out the Chip Address          *
*          *
*          * READ FROM SLAVE 68307 Mbus          *
*          * Write Chip Address, and READ Two bytes of data          *
*          *
*          BSR          MBBUSY          Poll the MBUS, wait till bus free          *
*          *
*          MOVE.B          #DRXCNT,V_DRXCNT          Data RECEIVE COUNT          *
*          MOVE.B          #ATXCNT,V_ATXCNT          Address TRANSMIT COUNT          *
*          MOVE.B          #0,V_DTXCNT          Data TRANSMIT COUNT          *
*          MOVE.B          #0,V_WRITE          Set Write to slave var = FALSE          *

```

```

        MOVE.B   #S307_AD,D6           Alter chip address lsb for
        OR.B     #01,D6                slave transmit and
        MOVE.B   D6,V_CHIPAD          write to chip address variable
        MOVE.L   #S307_DATA,A0        Pointer to data for memory 1

        BSR     WRITE1                Send out the Chip Address

* Test Complete
        BSR     MBBUSY                Poll the MBUS, wait till bus free
FOREVER  BRA     FOREVER              Test complete & passed, loop forever

*****
* MBUS SETUP/INITIALISATION
*****
INIT_MBM  MOVE.W   #2700,SR           DISABLE INTERRUPTS BY SETTING TO LEVEL 7
          MOVE.B   #0,MBSR           CLEAR INTERRUPT PEND, ARBITRATION LOST
          MOVE.B   #0C,MFDR          SET FREQUENCY
          MOVE.B   #00,MBCR          DISABLE AND RESET MBUS
          MOVE.B   #80,MBCR          ENABLE MBUS
          RTS

* NOTE - By not writing MADR, the 68307 MBUS slave address = 0

*****
* Poll the MBUS BUSY
*****
MBBUSY   BTST    #5,MBSR             TEST MBB BIT,
          BNE     MBBUSY             AND WAIT UNTIL IT IS CLEAR
          RTS

*****
* GENERATION FIRST BYTE OF DATA TRANSFER
*****
WRITE1   BTST    #5,MBSR             TEST MBB BIT,
          BNE     WRITE1             AND WAIT UNTIL IT IS CLEAR

TXSTART  BSET    #4,MBCR             SET TRANSMIT MODE
          BSET    #5,MBCR             SET MASTER MODE (GENERATE START)
          BSET    #6,MBCR             Enable MBUS Interrupts
          MOVE.B   (V_CHIPAD),MBDR    TRANSMIT THE SLAVE CHIP ADDRESS
          MOVE.W   #2000,SR           ENABLE INTERRUPTS BY SETTING TO LEVEL 0

MBFREE   BTST    #5,MBSR             TEST MBB BIT,
          BEQ     MBFREE             If bus is still free, wait until busy
          RTS

*****
* POST BYTE TRANSMISSION/RECEPTION SOFTWARE RESPONSE
*****
ISR      ORG     MBUSHAN              Start of Interrupt Handler
          BCLR    #1,MBSR             CLEAR THE MIF FLAG
          MOVE.L  D0,-(A7)            PUSH D0 REGISTER TO STACK
          MOVE.L  D1,-(A7)            PUSH D1 REGISTER TO STACK
          MOVE.L  #0,D0               Clear general data reg
          MOVE.L  #0,D1               Clear general data reg

          BTST    #5,MBCR             CHECK THE MSTA FLAG
          BEQ     SLAVE               BRANCH IF SLAVE MODE

          BTST    #4,MBCR             CHECK THE MODE FLAG
          BEQ     MASTRX              BRANCH IF RECEIVE MODE

*****
* Master TRANSMIT caused Interrupt
*****
MASTX    BTST    #0,MBSR             CHECK ACK FROM RECEIVER,
          BNE     ENDMASTX            IF NO ACK, END TRANSMISSION

TXADDR   MOVE.B   V_ATXCNT,D1         CHECK Address TX COUNT
          BEQ     TXDATA              If address already Complete go to data
          SUBQ.B  #1,V_ATXCNT         Decrement Address Tx Count

TXDATA   MOVE.B   V_WRITE,D1          Check if writing or reading slave
          BEQ     SETMASTRX           If reading set to Master receive

          MOVE.B   V_DTXCNT,D1         CHECK Data TX COUNT
          BEQ     ENDMASTX            IF NO MORE DATA THEN STOP BIT
          SUBQ.B  #1,V_DTXCNT         Reduce Tx Count
          MOVE.B   (A0)+,MBDR          Transmit next byte
          BRA     END                 EXIT

ENDMASTX BCLR    #5,MBCR             GENERATE STOP CONDITION
          BRA     END                 EXIT

SETMASTRX BCLR    #3,MBCR             Enable TXAK
          BCLR    #4,MBCR             Set master Receive Mode
          BSET    #5,MBCR             SET MASTER MODE (GENERATE START)

```

```

*****
* Master RECEIVE
*****
MASTRX      SUBQ.B   #1,V_DRXCNT      Decrement receive count
            MOVE.B   V_DRXCNT,D1
            CMP.B    #DRXCNT-1,D1      First byte read Check
            BNE     NOTFIRST          If not first, read and compare as usual
            MOVE.B  MBDR,D0           If first, DUMMY read only to start Rx
            BRA     END

NOTFIRST    CMP.B    #0,D1
            BEQ     ENMASR            LAST BYTE TO BE READ CHECK
            SUBQ.B  #1,D1            LAST SECOND BYTE TO BE READ CHECK
            BNE     NXMAR            NOT LAST ONE OR LAST SECOND,SO BRANCH

LAMAR      BSET    #3,MBCR            LAST SECOND, DISABLE ACK TRANSMITTING
            BRA     NXMAR

ENMASR     BCLR    #5,MBCR            LAST ONE, GENERATE STOP SIGNAL

NXMAR      MOVE.B  MBDR,D0           READ DATA
            CMP.B  (A0)+,D0          COMPARE WITH WRITTEN DATA
            BEQ     END              If data as expected o.k.

READERR    BRA     READERR          Else ERROR loop forever.

END        MOVE.L  (A7)+,D1          POP D1 REGISTER FROM STACK
            MOVE.L  (A7)+,D0          POP D0 REGISTER FROM STACK
            RTE

SLAVE      NOP
            BRA    SLAVE            SLAVE OPERATION NOT IMPLEMENTED

*****
* Buffers and Variables
*****
V_WRITE    DC.B    $1                Slave write = True
V_CHIPAD   DC.B    S307_AD           Chip Address variable = Slave 307 Add
V_DRXCNT   DC.B    DRXCNT           Set up variables - Data Receive Count
V_ATXCNT   DC.B    ATXCNT           - Addr Transmit Count
V_DTXCNT   DC.B    DTXCNT           - Data Transmit Count
S307_DATA  DC.B    $AA,$55          Chip 1 Data

            END

```

Software Listing 2 - M-bus Slave Software

```

*****
*          MOTOROLA 68307 IMBP TEST BOARD - MBUS          *
*-----*
*          MODULE:  MBS_INT.SRC          DATE:    8/4/94    *
*          *
*    Developed by : Motorola              *
*          HI-END Applications            *
*          East Kilbride.                *
*          *
* NOTES:                                     *
* Slave MBUS Routine using interrupts for a Master/Slave Test *
*          *
* The number of bytes transmitted and received is completely *
* controlled by the master. (i.e. When the slave is receiving data, *
* it acknowledges all the time, and the master dictates the number of *
* bytes to transfer. When the slave is transmitting, the master *
* receiver acknowledges dictate whether the slave is to send further *
* bytes or not.) *
*          *
* The Slave: *
* 1) Recognises its slave chip address, and receives 2 data bytes. *
* 2) Recognises its slave chip address, and transmits the 2 bytes. *
*          *
*-----*
*          EXTERNAL REFERENCE DECLARATIONS *
*-----*
*          XREF      SCR          System Control Reg
*          XREF      PBCNT        Port B Control Reg
*          XREF      PIVR        Peripheral Interrupt Vector Reg
*          XREF      PICR        Peripheral Interrupt Control Reg
*          XREF      MADR        MBUS Address Reg
*          XREF      MFDR        MBUS Freq Divider Reg
*          XREF      MBCR        MBUS Control Reg
*          XREF      MBSR        MBUS Status Reg
*          XREF      MBDR        MBUS Data Reg
*
*-----*
*          Constants
*-----*
UVECBASE EQU $100          User Vector Base
MBUSVEC  EQU UVECBASE+($D*4) MBUS vector location
MBUSHAN  EQU $15000       MBUS Interrupt Handler location

S307_AD  EQU $66          Slave 68307 MBus Address
*-----*
*          Main Program
*-----*
          ORG      $10000      RANDOM LOCATION FOR ASSEMBLY
          AND.L    #FFFFFFF,SCR Clear SCR bit 8, MBUS CLock Active
          MOVE.B  #$40,PIVR    Vector = #$40, Vector @ address $100
          OR.W    #$000D,PICR   MBUS Interrupt level = 5
          MOVE.L  #MBUSHAN,MBUSVEC Set up MBUS Interrupt Handler
          OR.W    #$0003,PBCNT   Enable MBUS Lines
          BSR     INIT_MBS      Initialise MBus as slave

FINISH   BRA      FINISH      Loop forever

*****
* MBUS SETUP/INITIALISATION
*****
INIT_MBS MOVE.W  #$2700,SR      DISABLE INTERRUPTS BY SETTING TO LEVEL 7
          MOVE.B  #0,MBSR      CLEAR INTERRUPT PEND, ARBITRATION LOST
          MOVE.B  #$10,MFDR     Set FREQUENCY
          MOVE.B  #S307_AD,MADR Set MBUS slave address
          MOVE.B  #$00,MBCR     DISABLE AND RESET MBUS
          OR.B    #$C0,MBCR     ENABLE MBUS, Ints, TXAK
          MOVE.W  #$2300,SR     Enable INTS BY SETTING TO LEVEL 3
          RTS

*****
* Poll the MBUS BUSY
*****
MBBUSY  BTST    #5,MBSR        TEST MBB BIT,
          BNE    MBBUSY        AND WAIT UNTIL IT IS CLEAR
          RTS

```

```

*****
* POST BYTE TRANSMISSION/RECEPTION SOFTWARE RESPONSE
*****
      ORG      MBUSHAN          Start of Interrupt Handler
ISR    BCLR     #1,MBSR         CLEAR THE MIF FLAG
      MOVE.L   D0,-(A7)        PUSH D0 REGISTER TO STACK
      MOVE.L   D1,-(A7)        PUSH D1 REGISTER TO STACK
      MOVE.L   #0,D0           Clear general data reg
      MOVE.L   #0,D1           Clear general data reg

* Interrupt Counter
      ADDQ.L   #1,D3           (Not used, simply monitor)

      BTST    #5,MBCR         CHECK THE MSTA FLAG
      BEQ     SLAVE          BRANCH IF SLAVE MODE

MASTER  BRA     MASTER        Master not implemented, so error

*****
SLAVE   MOVE.B  MBSR,D6        Read MBSR
      BTST.B  #6,D6          Is it slave address byte?
      BEQ     SLAVE_DATA     If not, then data

*****
* Addressed as SLAVE
*****
SLAVE_ADD  BTST    #2,D6        Read SRW to verify slave Tx or Rx
          BEQ     INIT_SRX     If Rx, initialise SLAVE receive count

INIT_STX  OR.B    #$10,MBCR     Set transmit mode
          MOVE.L  #DATABUF,A0   Pointer to data storage buffer
          MOVE.B  (A0)+,MBDR    First data byte transmit
          BRA     END_SLAVE

INIT_SRX  AND.B  #$E7,MBCR     Set receive mode and TXAK
          MOVE.L  #DATABUF,A0   Pointer to data storage buffer
          MOVE.B  MBDR,D0       Start receive via Dummy byte read
          BRA     END_SLAVE

*****
* Slave Data
*****
SLAVE_DATA  BTST    #4,MBCR     Read Tx or Rx mode
          BEQ     SRX_DATA

*****
* Post Slave data Transmit Control
*****
STX_DATA  BTST    #0,MBSR      CHECK ACK FROM RECEIVER,
          BEQ     NXT_TX       IF ACK, THEN TX NEXT DATA BYTE

          AND.B  #$EF,MBCR     TX complete so swap to Rx
          MOVE.B  MBDR,D0       Dummy read to free bus (SCL)
          BRA     END_SLAVE     Finish and await Master

NXT_TX    MOVE.B  (A0)+,MBDR    Tx next data byte
          BRA     END_SLAVE     EXIT

*****
* Post Slave data Receive Control
*****
SRX_DATA  MOVE.B  MBDR,D0       READ DATA
          MOVE.B  D0,(A0)+     Store data in next data buffer location

END_SLAVE  MOVE.L  (A7)+,D1     POP D1 REGISTER FROM STACK
          MOVE.L  (A7)+,D0     POP D0 REGISTER FROM STACK
          RTE

*****
* Buffers and Variables
*****
DATABUF  DS.B    0             Slave data buffer between Rx and Tx

      END

```

All products are sold on Motorola's Terms & Conditions of Supply. In ordering a product covered by this document the Customer agrees to be bound by those Terms & Conditions and nothing contained in this document constitutes or forms part of a contract (with the exception of the contents of this Notice). A copy of Motorola's Terms & Conditions of Supply is available on request.

Motorola reserves the right to make changes without further notice to any products herein. Motorola makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Motorola assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Motorola does not convey any license under its patent rights nor the rights of others. Motorola products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Motorola product could create a situation where personal injury or death may occur. Should Buyer purchase or use Motorola products for any such unintended or unauthorized application, Buyer shall indemnify and hold Motorola and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Motorola was negligent regarding the design or manufacture of the part. Motorola and  are registered trademarks of Motorola, Inc. Motorola, Inc. is an Equal Opportunity/Affirmative Action Employer.

The Customer should ensure that it has the most up to date version of the document by contacting its local Motorola office. This document supersedes any earlier documentation relating to the products referred to herein. The information contained in this document is current at the date of publication. It may subsequently be updated, revised or withdrawn.

Literature Distribution Centres:

ASIA PACIFIC: Motorola Semiconductors (H.K.) Ltd., Silicon Harbour Center,
No. 2, Dai King Street, Tai Po Industrial Estate, Tai Po, N.T., Hong Kong.

JAPAN: Nippon Motorola Ltd., 4-32-1, Nishi-Gotanda, Shinagawa-ku, Tokyo 141, Japan.

USA: Motorola Literature Distribution, P.O. Box 20912, Phoenix, Arizona 85036.

